



6. Postavi u definiciju macroa direktive `.SAVE_PSECT`,  
`.PSECT ARGUMENTI` i `.RESTORE_PSECT!`

```
        .MACRO  CALL      PROCEDURA,LISTA
N=0
        .IRP    X,LISTA
N=N+1
        .ENDR
ARG=.
        .LONG   N
        .IRP    X,LISTA
        .LONG   X
        .ENDR
        .CALLG  ARG,PROCEDURA
        .ENDM   CALL
```

## DODATNI ZADATAK

7. Kakav je sadržaj registra R5 na kraju tog dela programa?

```
N:      .LONG   10
```